



How to add Tiandy cameras to the Dahua NVR

In the main menu, click CAMERA



Click Manual Add



Enter needed information, then click OK.

Manual Add

Channel	16		
Manufacturer	Onvif		
IP Address	192.168.0.0		
RTSP Port	554	HTTP Port	80
User Name	admin		
Password	•••••		
Remote Channel	1		
Decoder Buffer	Default		

☒ Auto ☐ TCP ☐ UDP ☐ MULTICAST

OK Cancel

Manual Add

Channel	16		
Manufacturer	Onvif		
IP Address	192.168.0.0		
RTSP Port	554	HTTP Port	80
User Name	admin		
Password	•••••		
Remote Channel	1		
Decoder Buffer	Default		

☒ Auto ☐ TCP ☐ UDP ☐ MULTICAST

OK Cancel